

InView Configuration set up for PENTAX OPTIO E 20



General instructions

Best results are obtain when using the P program (automatic). Don't try to increase or reduce luminosity (EV menu) and always keep it on 0, and don't use the flash even if you feel that you have a dark image on the LCD monitor of the camera. Remember to try to stay as still as possible for best results.

Remember also that the Fisheye lens must be very clean (on both side) before you take a picture

Setting up the camera

1. Set up the camera on The P (Automatic) program
2. Set up the NO FLASH Mode.
3. While in the Program, Press the menu Button and make sure that you have the settings shown on the Pictures below



Recorded Pixels : **4M**
Quality Level : **AAAK (high)**
White Balance : **AWB (Auto)**
ISO Sensitivity : **Auto**



AE metering : **Center-weighted**
Digital Zoom : **On**
Instant review : **On**



Color : **FULL**
Sharpness : **High**
Saturation : **Medium**
Date Print : **Off**